



Quick Guide

G-Series+ DIGITAL VOICE PAGER

Dear Customer:
Thank you for purchasing the G-Series+ DIGITAL VOICE PAGER.
Please read the Quick Guide before operating the G-Series+ DIGITAL VOICE PAGER.

1. PAGER OVERVIEW

a. Pager Appearance

Front View



Side View



Rear View



Top View



b. Standard Accessories

▼Belt Clip ▼Type-C USB



NO.	Description
a-1	LED Indicator
a-2	Navigation Key
a-3	Soft Key (K1~K4)
a-4	Back Key (F2)
a-5	Main Menu (F1)
a-6	Speaker
a-7	Microphone
a-8	Receive Antenna
a-9	Channel Knob
a-10	Power on/off & Volume Knob
a-11	Play Key
a-12	Reset Key
a-13	Voice Memo Key (S1)
a-14	USB Type-C Port
a-15	Belt Clip
a-16	Battery Cover

2. OPERATION INTRODUCTION

a. Initial Use

Install Battery

- 1 Turn the screws and remove the battery cover.
- 2 Insert the battery pack into the G-Series+ Pager.
- 3 Replace the battery cover and tighten the screws.

Pressure Vent
Warning: Do not block. Warranty will be void if seal is broken.



Battery Charging

The G-Series + Pager uses a custom lithium-ion battery, which can be charged with the included cable and adapter (5V / 2A).

Power On

After the battery is installed, turn the volume knob clockwise to power on the G-Series+ Pager. You will hear a "click" sound and see the word "Loading" appear on the display screen.



b. LED Introduction




Power LED:

NO.	Product	Entity Key	Description
b-1	G2+ / G4+	Orange Light	● Charging
		Green Light	● Fully Charged
b-2	G3+ / G5+	Orange Light	● Charging
		Green Light	● Fully Charged

Message LED:


NO.	Product	Entity Key	Description
b-3	G2+ / G4+	Green Light	● Receiving voice call or data call
b-4	G3+ / G5+	Green Light	● Receiving voice call or data call

c. LCD Display



Standby Screen

On the standby screen, the G-Series+ Pager displays information on the current receiving mode.



Receive Message

The G-Series+ Pager displays the information of the incoming call when receiving a message.



d. Icon Introduction

Status Bar Icon

NO.	Item	Icon	Description
d-1	Trunking Status		Trunking Status Indicator: Site Trunking
d-2	Trunking Status		Trunking Status Indicator (Blinking): Out Of Range
d-3	Trunking Status		Trunking Status Indicator: In Range
d-4	Trunking Status		Trunking Status Indicator (Blinking): Control Channel Hunting
			Trunking Status Indicator: Control Channel Scanned
d-5	Battery Status		The battery gauge indicator is located on the status bar and keeps you informed of the battery level. The six levels of indication are as follows: Empty Battery: <=1% 1 Red Cell: 2% 1 Green Cell: 3% ~ 25% 2 Green Cells: 26% ~ 50% 3 Green Cells: 51% ~ 75% 4 Green Cells: 76% ~100%
d-6	On Duty		On Duty Indicator
d-7	Off Duty		Off Duty Indicator
d-8	Time Display		Time Display (24 Hour Format) Time Display (12 Hour Format - AM) Time Display (12 Hour Format - PM)
d-9	Bluetooth		Bluetooth is activated
d-10	Bluetooth Headset		Bluetooth Earphone is connected
d-11	Message Hint		Unread Message Indicator
d-12	Alarm Clock		Alarm Clock is activated
d-13	RF Strength		RF Signal Strength Indicator

Scan the QR code for User Guide >>>



- To ensure optimal reception performance, use the included accessories when charging and programming the device.

BATTERY NOTICE: Battery must be charged a minimum of 5 hours prior to usage.

IMPORTANT INFORMATION: For questions or help on your new G-Series+ device, you may reach our support team at (817) 303-9320

For more details, please refer to the G-Series+ user manual.

WE RESERVE THE RIGHT TO CHANGE TECHNICAL SPECIFICATIONS WITHOUT PRIOR NOTICE.



©2015 Unication Co., Ltd.
The information contained in this document is the exclusive property of Unication Co., Ltd. It shall not be disclosed, distributed or reproduced in whole or in part without written permission of Unication Co., Ltd.

Head Office
Unication Co., Ltd.
Tel.: +886-2-2299-9678
Address: 5F, No. 6, Wu-Kung 5 Rd.,
Hsinchuang District, New Taipei City, Taiwan
Email: salesenquiry@uni.com.tw

North America Branch Office
Unication USA Inc.
Tel.: +1-817-303-9320
Address: 1901 E. Lamar Blvd.,
Arlington, TX 76006, U.S.A.
Email: sales@unication.com

www.unication.com | Unication Logo, Unication, G-Series+ Logos and the G-Series+ are trademarks or registered trademarks of Unication